



## How to Layout Your Acculink Chain Link Fence System

Draw a diagram of your fence project with measurements of fence as shown.

This example requires 143 ft. of fencing and components, 7 Main Posts, 10 Line Posts and 1 Gate.

\*Posts should not be spaced more than 10 ft. apart



### Recommended List of Tools

- Post Hole Digger
- Wheelbarrow
- Shovel
- Tape Measure
- Level
- Plumb Line (String)
- Pliers
- 1/2 in. or 9/16 in Wrench
- Hacksaw or Pipecutter
- Stakes to lay out project

## Acculink Chain Link Fence Features

- PROVEN THE MOST DURABLE AND AFFORDABLE FENCING FOR YOUR HOME
- GALVANIZED AND COLOURED SYSTEMS TO SUIT EVERY STYLE AND BUDGET
- OPTIONAL PRIVACY INSERTS
- AS EASY TO INSTALL AS A "DO-IT-YOURSELF PROJECT"
- SPECIAL ORDER REQUIREMENTS AVAILABLE

### Ask Your Fence Retailer About the Following Acculink Fence Products:


- ORNAMENTAL IRON FENCE: *"New York Collection"*
- PORTABLE DOG KENNELS
- AGRICULTURAL FENCE PRODUCTS
- WELDED WIRE MESH PRODUCTS
- COMMERCIAL / INDUSTRIAL FENCE SYSTEMS



A Member of the Roma Fence Group of Companies



# CHAIN LINK FENCE HOW TO BOOKLET



## How to Install Your Acculink Chain Link System

To make sure you order all material required, draw a detailed diagram of the property to be fenced (see inside fold of brochure). Indicate all post and gate locations. Gate size is determined by the distance between the two posts it occupies, not the gate's actual frame measurement.


A main post is required wherever a change of direction is made in the fence, or where there is change in the elevation of the Top Rail.

Set Corner, Gate and End Posts in cement. Posts should be set out of the ground 1.5" higher than the height of the fence fabric used.


Set line posts in cement at a height of 1.5" lower than the height of fence fabric used. Height of posts can be lined up with a mason's line.


Install Line Post Caps, Top Rail (cut to fit) and Rail End Assembly.


Affix fence to posts, using Tension Bars and Offset Bands. Fasten fabric to Top Rail and Line Posts with Fence Ties. Run Brace Wire through the bottom of the fence and attach with Hog Rings or Brace Wire Ties.




1 Main Post Cap 

2 Rail End Assembly 

3 Swaged End Top Rail 




4 Line Post Cap 

5 Tension Bar 

6 Tension/Offset Band 

7 Fence Tie 

8 Hog Ring 

9 Gate Hardware Kit  
 • Gate Latch   
 • Frame Collar   
 • Post Collar 

## How to Order Your Acculink Fence System

Parts And Description	Quantity	Price	Parts And Description	Quantity	Price
MAIN POSTS (total "O" and "X")			FENCE TIES (1 per foot of fence & lineposts) - example 4 on a 4' high linepost x number of posts		
MAIN POST CAPS (same # as Main Posts)			LINE POSTS (1 post every 10 ft.)		
OFFSET TENSION BANDS (8 per corner, 4 per end)			LINE POST CAPS (1 per line post)		
TENSION BARS (2 per corner, 1 per end)			GATE(S)		
HOG RINGS (1 per 18" of perimeter)			CHAIN LINK FENCE WIRE		
RAIL END ASSEMBLIES (2 per corner, 1 per end)			BOTTOM BRACE WIRE		
TOP RAIL 10 ft. (1 piece per 10 ft. of fence)					
<b>Sub Total</b>			<b>Total</b>		